

Gebrauchsanweisung

Aufladen der Powerbank

- Verbinden Sie das USB-Kabel mit dem Micro USB Power Bank Input („5V IN“) und stecken Sie das andere Ende in den USB-Zugang des Computers oder einer anderen Stromquelle.
- Anmerkung: Die Powerbank muss VOLL geladen werden – circa 5 Stunden Akkuladezeit.

Laden von Smartphones oder anderen USB-Geräten

- Bringen Sie das USB-Kabel im Output („5V OUT“) an.
- Stecken Sie den Anschluss des jeweiligen Gerätes am anderen Ende an.
- Es ist möglich Ihr eigenes USB-Kabel zu verwenden.

Sicherheitsanweisungen und Instandhaltung

- Schützen Sie das Gerät vor extremer Hitze bzw. Kälte, direkter Sonneneinstrahlung, Wasserkontakt, Feuchtigkeit und jeglicher Art von Flüssigkeiten.
- Benutzen Sie zur oberflächlichen Reinigung keine aggressiven Putzmittel und halten Sie es fern von scharfen Objekten.
 - Halten Sie das Gerät staubfrei.
 - Halten Sie das Gerät von Kindern fern.
- Werfen Sie das Gerät nicht in Feuer (Explosionsgefahr)
 - Bauen Sie das Gerät nicht eigenständig auseinander.
- Reparaturarbeiten sollten nur von einer qualifizierten Person durchgeführt werden.
- Benutzen Sie das Gerät NICHT, wenn es feucht geworden ist, um der Gefahr von Elektroschocks und Explosionen vorzubeugen.
- Benutzen Sie diese Einheiten NICHT, wenn sie fallen gelassen wurde oder anderweitig beschädigt wurde.

DIES IST KEIN SPIELZEUG

Weitere Angaben:

Input - DC 5V - 1000MA (max)
Output - DC 5V - 1000mA (max)
Kapazität – 4000 mAh
Integrierte Überladungssperre

30825 | PO 0911247

reg.no.: 72005675

Easy Gifts GmbH, Thomas-Mann-Str. 60, DE 90471 Nürnberg

Die Konformitätserklärung zu diesem Produkt finden Sie unter:

http://data.promotray.de/Konformitaetserklaerungen/082503_pdf



Instruction Manual

Charging the Power Bank

- Connect USB cable with Micro USB charging head into power bank INPUT ("5V IN") and place the other end into the computer USB port or another power source
- Note: power bank has to be fully charged – approx. 5 hrs before usage

Charging smart phone or USB chargeable device

- Insert USB head into OUTPUT ("5V OUT")
- Add relevant charger head to opposite end and insert into your device
- It is acceptable to use your own USB charger cable

Safety Instructions, care and maintenance

- Keep the unit away from extreme high and low temperatures, out of direct sunlight and away from water, humidity and any liquids
 - Do not use abrasive solvents and do not expose to sharp objects
 - Keep the unit free of dust, lint, etc.
 - Keep out of reach of children
 - Do not throw the unit into a fire (risk of explosion)
 - Do not attempt to disassemble device
 - Repairs to electrical equipment should only be performed by a qualified electrician
- DO NOT use if the unit is moist in order to avoid danger of electric shock, explosions or injuring yourself
- DO NOT use if the unit has been dropped or damaged

THIS IS NOT A TOY

Additional Specifications:

Input - DC 5V - 1000MA (max)

Output - DC 5V - 1000mA (max)

Capacity – 4000 mAh

Built-in over charge protection

30825 | PO 0911247

reg.no.: 72005675

Easy Gifts GmbH, Thomas-Mann-Str. 60, DE 90471 Nürnberg

You can download the declaration of conformity on:

<http://data.promotray.de/Konformitaetsserklaerungen/082503.pdf>

